

---

## WMBUS DATA FORMAT

---

LEAKAGE DETECTION DEVICE (LAN-WMBUS-G2-LDS)

LEAKAGE DETECTION DEVICE (LAN-WMBUS-G2-LDP)



## Verify correct device and version

This document applies to the devices LAN-WMBUS-G2-LDS and LAN-WMBUS-G2-LDP with protocol version 7. There are two ways of finding out the protocol version of the device; either by looking at the label on the device or by looking at the data packets sent out by the device. See chapters **Protocol version in data packets** and **Protocol version in label** below for more information.

### Protocol version in data packets

If it is possible to check the information in the data packets sent out by the device, then the protocol version is included in the data field called *A-Field Protocol version*. For more information, see chapter **WMBUS-format**.

### Protocol version in label

The protocol version can be found on the label. An example of a label is shown in the figure below and the relevant information is described by LAS.00046146.1E.08, where

- **Manufacturer code:** LAS
- **Serial number:** 00046146
- **Device type:** 1E
- **Protocol version:** 08

**LANSSEN**

**LAN - WMBUS - G2 - LDS**

**LAS.00046146.1E.08**

**M-Bus**)))

**CE**



**www.lansen.se**  
**Made in Sweden**

## WMBUS-format

Art nr.	LAN-WMBUS-G2-LDS and LAN-WMBUS-G2-LDP
Version	8p (0x08)
Information	Packet is sent every 90 seconds (default, can be configured) in T-mode. Packet is also sent immediately when water is detected or when leakage is restored.
DR1	Leakage status
DR2	Error messages
DR3	Current leakage value on port 1 <b>Note:</b> Value is between 0-1023, where 1023 is completely dry.
DR4	Current leakage value on port 2 <b>Note:</b> Value is between 0-1023, where 1023 is completely dry.

Byte No	Field Name	Content	Info	Byte data	
1	L-Field	Length			Linklayer
2	C-Field	SND-NR		0x44	
3	M-Field	Meter Manufacturer code	LAS	0x33	
4	M-Field	Meter Manufacturer code		0x30	
5	A-Field	Meter serial number (LSB)	<b>Example:</b> 0001067	0x67	
6	A-Field	Meter serial number		0x00	
7	A-Field	Meter serial number		0x01	
8	A-Field	Meter serial number (MSB)		0x00	
9	A-Field	Protocol version		0x0B	
10	A-Field	Meter type	Leakage Sensor	0x1E	
11	CI-Field	Short header		0x7A	Networklayer
12	Access no.	Transmission counter	<b>Example:</b> 7	0x07	
13	Status	Device status (error/alarms)	Refer to <b>Table 1</b> for possible values	0x00	
14	Configuration	Number of encrypted blocks	<b>Example:</b> 3	0x03	
15	Configuration	Encryption		<b>No encryption:</b> 0x00 <b>Encryption mode 5:</b> 0x05	
16	AES-Verify	Encryption Verification		0x2F	
17	AES-Verify	Encryption Verification		0x2F	
18	DR1	DIF	2-byte integer	0x02	Leakage status
19	DR1	VIF	Extension table	0xFD	
20	DR1	VIFE	Digital input	0x1B	
21	DR1	Value (LSB)	Refer to <b>Table 2</b> for possible values	0x00	
22	DR1	Value (MSB)		0x00	
23	DR2	DIF	2-byte integer	0x02	Error messages
24	DR2	VIF	Extension table	0xFD	
25	DR2	VIFE	Error flags (16-bit)	0x97	
26	DR2	VIFE		0x1D	
27	DR2	Value (LSB)	Refer to <b>Table 3</b> for possible values	0x00	
28	DR2	Value (MSB)		0x00	
29	DR3	DIF	2-byte integer	0x02	Leakage value port 1
30	DR3	VIF	Extension table	0xFD	
31	DR3	VIFE	Dimensionless	0x3A	
32	DR3	Value (LSB)	<b>Example:</b> 1023 (0x03FF)	0xFF	
33	DR3	Value (MSB)		0x03	
34	DR4	DIF	2-byte value	0x82	Leakage value port 2
35	DR4	DIFE	Subunit 1	0x40	
36	DR4	VIF	Extension table	0xFD	
37	DR4	VIFE	Dimensionless	0x3A	
38	DR4	Value (LSB)	<b>Example:</b> 1023 (0x03FF)	0xFF	
39	DR4	Value (MSB)		0x03	

Table 1: Status byte with errors and alerts

Bit	Info
0 (0x01)	X
1 (0x02)	X
2 (0x04)	Low battery
3 (0x08)	X
4 (0x10)	X
5 (0x20)	Leakage detected
6 (0x40)	X
7 (0x80)	X

Table 2: Digital input values

Bit	Info
0 (0x01)	Leakage detected on port 1
1 (0x02)	Leakage detected on port 2

Table 3: Error flag values

Bit	Info
0 (0x01)	X
1 (0x02)	Low battery