LANSEN


QUICK INSTALLATION GUIDE

LEAKAGE DEVICE [G2-LDP]



Recommended mounting instructions:

- For best horizontal range, place the device upright
- For best vertical range, place the device horizontally
- For maximum range, mount the device and receiver so they have the same polarization
- Avoid placing directly against metallic objects to maximize range
- Mount with either double-sided tape or screws




Step 1a (left):

Open the device using a torx screwdriver on the front screw. Unscrew by turning counterclockwise.

Step 1b (right):

Separate the back piece by using, for example, a screwdriver at the bottom of the device as in the right picture.

Once opened, the PCB will be visible on the inside.




Step 2a (Mounting with screws):

Mount the back piece to a wall according to the recommended mounting instructions on the beginning of this guide.

Fasten the screws in the holes marked by red in the picture and then go to **Step 3**.

Step 2b (Mounting with double sided tape):

Stick the double-sided tape onto the back piece and mount the device to a surface according to the recommended mounting instructions on the beginning of the guide. Skip to Step 5.




Step 3a (left):

See picture in **Step 2** on the orientation of the device, then insert the top part of the front piece onto the top part of the back piece (1).

Step 3b (right):

Insert the bottom part of the front piece onto the bottom part of the back piece (2).



Step 4:

Put the torx screw from **Step 1** in the hole at the front and tighten the screw using a torx screwdriver.

Make sure that the device is securely mounted.


At first startup, the device is put in sleep mode.

Activate the device according to Step 6.

Step 5:

The device is in sleep mode when delivered.

Activate the device according to Step 6.



Step 6 (Activate by using water on white cable)

Connect the black/white conducting leakage cable to the black non-conducting cable if it's not already connected. Dip the side of the black/white leakage cable in water — the red LED on the front of the device will turn on when water is detected.

Once the LED starts flashing, the startup sequence has been initiated - remove the leakage cable from the water and wipe off excess water to start the sequence. Once the LED stops flashing, the startup sequence is complete.

Note: Using water to active device is to ensure proper functionality of the product.

Note: Avoid dipping the black end cap in water. Water can get stuck inside and give false alarms.

Note: During the first four minutes after startup, the device will check for water every 10 seconds. If water is detected during the first four minutes, the red LED at the front will be ON. As soon as it doesn't detect water, the LED is turned OFF.

Note: After the first four minutes, the device will check for water every 30 seconds. In this case, the device will behave as follows:

- First 30 seconds after water is detected: Blink once every two seconds
- After 30 seconds up to 18 hours: Blink once every 30 seconds

Step 7:

Mount the leakage cable at the area where leakage needs to be detected. Make sure the leakage cable is mounted directly against the surface which is monitored by using the supplied clips or by using straps.

Note: Mount the strap/clip closest to the black end cap maximum 10 cm away from the black end cap to ensure the cable is firmly mounted against the surface.

Installation is complete!